



## FLP-5033NKPM



## TEMP.&amp; WATER PRESSURE REQUIREMENTS




Working Pressure: 1~3 bar





Required Temperature: 5-65°C

Note: Above are the recommended values for getting Conventional Output.

## TECHNICAL DRAWING









	<p>Apply soft cotton cloth</p>		<p>Apply soft cotton cloth</p>
<p><b>✗ DON'T</b></p>	<p>Don't apply Scrub</p> <p><b>✗ DON'T</b></p>	<p><u>Steps &amp; Cleaning agents requirements for Aerator Cleaning.</u></p> <div data-bbox="1114 845 1860 1282"> <p>Aerator      1 hour Dip      De-Scale Water      Liquid Soap PH-5-7</p> </div>	